

### CHARACTERISTICS

Functional features:

1. The magnetic top make it convenient to clean and replace the atomizer.
2. Draw activated and button activated modes are easy to operate.
3. Three-mode voltage settings meeting different needs
4. Capacity of battery: 400MAH
5. Charging current: 400MA
6. Charging input voltage: USB 5V

### HOW TO USE

1. Put the compatible 510 cartridge in place.
2. Press the power button 5 times within 2 seconds to turn on the device. The indicator light flashes white 3 times and then enters the voltage mode.
3. Press the power button 2 times within 0.8 second to change the voltage: blue > purple > white > blue.  
**Mode 1:** Blue – 3.2V  
**Mode 2:** Purple – 3.6V  
**Mode 3:** White – 3.9V
4. Enter the session mode by pressing the power button for 3 times within 2 seconds. The indicator light flashes pink. The preheating lasts 10 seconds. Stop the session by pressing the power button.
5. The vape can be used automatically through inhale activation without pressing the button. If it fails to activate (e.g.: due to a clogged cartridge), you can press and hold the button to vape for up to 10s. After 10s the device will stop heating and return to standby.
6. Press the button 5 times within 2s to turn off the device. (The indicator light will flash 3 times.)

### ALARMS IN CASE OF ABNORMALITY

1. Low battery alarm: The light flashes red 8 times. Please charge the device before use.
  2. Open-circuit alarm: The light flashes yellow 5 times. Please replace the atomizer before use.
  3. Short-circuit alarm: The light flashes yellow 8 times. Please replace the atomizer before use.
- Timeout protection | Overcharging protection  
Short-circuit protection | Low battery protection

### CHARGING STATUS OF LED LAMP

1. Battery is charging: When charging the light will flash red three times and then keep pulsing as the device charges.
2. Battery is fully charged: The light is constantly blue while the USB is connected.

### KIND REMINDER

For better understanding and using this device, please carefully read this manual prior to the first use.

1. This product is not intended for use by persons under legal smoking age, nonsmokers, women who are pregnant or breastfeeding, or persons with or at risk of heart disease, high blood pressure, diabetes, or persons taking medicine for depression or asthma
2. Battery built-in the device. Please do not expose the device to high temperature, cold or humid environments.
4. Turn off the device when not in use.

### WARRANTY

30 days from the date of purchase against manufacture defects. Does not apply to improper use.



MADE IN CHINA  
www.lookah.com  
ORIGINAL DESIGNED BY LOOKAH



LOOKAH®  
ORIGINAL DESIGN ONLY



TURTLE  
USER MANUAL

